

INDUSTRIAL ENCLOSURES

BY TRICEL

40+ YEARS
TECHNICAL
EXPERIENCE



IP66 ELECTRICAL ENCLOSURE

400 x 300 x 200MM SURFACE

FIRE RETARDANT TO BS 476, PART 7, 1997, CLASS 2

STOCK CODE: 105018



TRICEL
CONSTRUCTION

STOCK CODE:
105018

IP66 ELECTRICAL ENCLOSURE


400 x 300 x 200MM SURFACE

FIRE RETARDANT TO BS 476, PART 7, 1997, CLASS 2

**INDUSTRIAL
ENCLOSURES**
BY TRICEL

40+
YEARS
TECHNICAL
EXPERIENCE

Compliant with IEC 62208 (2011) - Empty enclosures for low-voltage switchgear and control gear assemblies.



Example: IP66 Electrical Meter Box

DIMENSIONS

Internal dimensions: 366mm high x 256mm wide x 183mm deep

Outside dimensions: 400mm high x 300mm wide x 200mm deep

SPECIFICATION & KEY FEATURES

- IP66 rating suitable (EN 60529) suitable for electrical installations
- Certification of compliance with IEC 62208 (2011)
- Suitable for indoor or outdoor use
- Constructed from fire retardant GRP – Glass Reinforced Polymer.
- Fire retardant to BS 476, Part. 7, 1997, Class 2.
- Will not corrode, weather resistant.
- Complete with hinges, lock and key.
- Suitable for meters, electrical equipment, compressors, CCTV, industrial automation, marine etc.

Note: any electrical equipment fitted to Tricel enclosures must be completed by an appropriately qualified person.

* Approximate dimensions.

In accordance with Tricel's normal policy of product development these specifications are subject to change without notice.

TRICEL UK

Tel: +44 (0)1453 791616

Registered number 02868648

TRICEL IRL

Tel: +353 (0)64 663 2421

Registered number IE 075014

STOCK CODE:
105018

IP66 ELECTRICAL ENCLOSURE


400 x 300 x 200MM SURFACE

FIRE RETARDANT TO BS 476, PART 7, 1997, CLASS 2

**INDUSTRIAL
ENCLOSURES**
BY TRICEL

40+ YEARS
TECHNICAL
EXPERIENCE


ASSEMBLY FITTING THE HINGES:



1. Align the door to the hinges on the enclosure.
2. Push the supplied pins into place, ensuring they go through both enclosure hinge and door.
3. Tap lightly with a hammer if necessary.
4. Follow the same procedure for the bottom hinge.



INSTALLING THE BASE PLATE:



1. Get the supplied polyester base plate and align it with the holes in the enclosure.
2. Using the provided screw, align with the holes and screw into place.
3. Tighten with a drill or screwdriver.



* Approximate dimensions.

In accordance with Tricel's normal policy of product development these specifications are subject to change without notice.

TRICEL UK

Tel: +44 (0)1453 791616

Registered number 02868648

TRICEL IRL

Tel: +353 (0)64 663 2421

Registered number IE 075014