### METER BOXES BY TRICEL









Works with Tricel and Mitras Mark 2 Recessed Gas Meter Boxes

# Tricel SMC Gas Overbox (GRP Mark 2 Overbox)

GRP Overbox and Door to suit damaged recessed meter boxes. This GRP Overbox (Door frame kit) comes with a tapered back to fit standard Irish Gas meter boxes.




COMPLIANT GAS NETWORKS IRELAND STANDARD AM-SP 055 STOCK CODE: 105097

## Tricel SMC Gas Overbox (GRP Mark 2 Overbox)

**COMPLIANT GAS NETWORKS IRELAND STANDARD AM-SP 055** 







**Dimensions of GRP GAS Overbox** 

610mm high x 457mm wide x 95mm deep. Internal dimensions = 519mm high x 352mm wide\*

#### **SPECIFICATION & KEY FEATURES**

- GRP Overbox, repair solution for damaged Gas Recessed Meter Boxes.
- Compliant to GNI standards AM-SP-055 (2020).
- Compatible with all Ireland and Northern Ireland Gas Recessed Meter Boxes.
- Constructed from SMC / GRP Glass Reinforced Polymer.
- · Will not corrode, weather resistant.
- · Easily cleaned.
- Hinges on left.
- · Suitable for buildings with red bricks.

#### **INSTALLATION**

**Step 1:** Ensure that the GRP Overbox that you want to fit is the correct one for the box on the wall.

The Damaged Box on the wall should be approximately:

- Height = 595mm to 600mm
- Width = 410mm to 412mm
- Depth (outside of box to wall) = 70mm to 75mm





\* Approximate dimensions

In accordance with Tricel's normal policy of product development these specifications are subject to change without notice.

## Tricel SMC Gas Overbox (GRP Mark 2 Overbox)

**COMPLIANT GAS NETWORKS IRELAND STANDARD AM-SP 055** 

METER BOXES

40+
TECHNICAL
EXPERIENCE

Step 2: Remove the existing door, clean the box architrave and inspect for damage. Any damage (holes or cracks) should be filled using a 4-hour Fire Retardant Silicone (Only ESB Approved Silicone should be used, we recommend



106164 – FR200 Silicone which can be bought separately). This will ensure that water does not enter the cabinet.

**Step 3:** After unpacking the GRP Overbox, remove the door. This can done by depressing the brass insert hinge with a narrow screwdriver.



Step 4: Place the GRP Overbox over the damaged box on the wall. Ensure that you have a good fit (incorrect installation of the box on the wall may hinder this).



Step 5: Mark the holes on the wall from the overbox fitting holes.



Step 6: Drill holes using M6 Drill bit at a depth of 30mm.



Step 7: Insert supplied wall plugs into the wall.



\* Approximate dimensions.

rapproximate summands. In accordance with Tricel's normal policy of product development these specifications are subject to change without notice.

### Tricel SMC Gas Overbox (GRP Mark 2 Overbox)

**COMPLIANT GAS NETWORKS IRELAND STANDARD AM-SP 055** 







Step 8: Align the overbox to the holes drilled on wall, and fix to the wall using supplied M5x30mm screws.



**Step 9:** Close the door and test the fit.

**Step 10:** You may need to seal the architrave to the wall to fill in gaps. Only FR200 4-Hour Fire Retardant Silicone is recommended.

#### **ASSOCIATED PRODUCTS**



REPLACEMENT METAL KEY FOR ELECTRIC AND GAS METER BOXES (221439)



4-HOUR FIRE RETARDANT SILICONE (106164)





\* Approximate dimensions.

In accordance with Tricel's normal policy of product development these specifications are subject to change without notice.